



MSX500

X-Ray Inspection System

Operation Manual

M.S.Engineering Co. , Ltd.

〒222-0033 2-17-11,Shinyokohama Kohoku-Ku

Yokohama-shi. Kanagawa-Ken. Japan.

TEL +81-45-472-6441

FAX +81-45-472-6432

<http://www.mseng.co.jp>

CONTENTS

1. Safety Precautions and request	3
2. Nomenclature	5
2-1. Out Side Drawing	5
2-2. Front View of the System	6
3. Original Structure	7
3-1. Image Magnification.....	7
3-2. X-Ray Generator and CCD Camera.....	7
4. Operation Checkout	8
4-1. Control Panel.....	8
4-2. Circuit Breaker.....	9
4-3. X-Ray Interlock.....	10
4-4. Indication Lamp for X-Ray Operation	10
5. Principal Specifications	11
6. Warranty.....	12
7. Vision System	13
7-1. Abstract.....	13
7-2. Operation procedure.....	14
7-3. LIVE picture control.....	15
7-4. integrated picture control.....	16
7-5. Data Save.....	17
7-6. Cross Cursor	17

1. Safety Precautions and request

Thank you for purchasing the X Ray Inspection System MSX500. So that you can fully utilize the various feature of the system and to ensure correct and safe operation, please carefully read the following warnings / precautions.



Warnin

To prevent serious injury or server damage to the system, please observe the following warnings before using the system.



Caution

To prevent abstract or server damage to the system, please observe the following warnings before using the system.

 Warning	<p>Do not touch the electric plug by the wet hand.</p> <ul style="list-style-type: none"> ● There is fear of an electric shock
 Warning	<p>Never disassemble or modify of the system, in except for maintenance by the engineer.</p> <ul style="list-style-type: none"> ● It may break down or it may become the cause of the accident.
 Warning	<p>Please keep the electrical ground level with the grounding terminal. In case you deal with the inside of the control board, please fully check that the power supply is off.</p> <ul style="list-style-type: none"> ● There is fear of an electric shock.
 Warning	<p>Please check periodically whether dust has adhered to the circumference of the edge of a power supply plug, and the pug is inserting to the socket certainly.</p> <ul style="list-style-type: none"> ● It may the cause of an electric shock and a fire.
 Warning	<p>Please cut off power supply when cleaning and check of the system.</p> <ul style="list-style-type: none"> ● It may the cause of an electric shock and a injury.
 Caution	<p>Please do not damage the power supply cable. For example, Processing, Banding, Putting a weight, Inserts.</p> <ul style="list-style-type: none"> ● It may the cause of an electric shock and fire.




Caution

Please be sure to extract with a plug when the pulling out the plug of the cable. Do not it with the cable.


- It may the cause of an electric shock and fire.

2. Nomenclature

2-1. Out Side Drawing



2-2. Front View of the System



3. Original Structure

3-1. Image Magnification


Image Magnification	30X
----------------------------	------------

* Magnification is image rate on the CRT.

3-2. X-Ray Generator and CCD Camera

The X Rays generated from
The X-Ray Generator, then penetrate
the sample.

The CCD camera changed it into
the image.



- ① If X-Ray tube voltage is high, the frequency is going up, and the penetration will be upped.
If X-Ray tube current is high, Luminosity of the image will be goes up, but frequency of the X-Ray is not change.


- The monitor's image has reverse of the front and the back. But the right and the left are remains.

4. Operation Checkout

4-1. Control Panel

(a) Power Switch


- 「ON」 System is in standby.
- 「OFF」 System is stopped.




Power supply to the PC from the system will be always ON.
ON-OFF of the PC is based on the own switch of the PC.

(b) Table control Switch

- The table moves in the same direction as the pushed switch.
- The table is moved while pushing the switch.



(c) X-Ray System



- 「ON■OFF」 Switch is for X-RAY generator.
 - If it turns ON, X-Ray will be irradiated, and the lamp of the switch is lighting. Simultaneously, The indicator lamp of the X-Ray will be lighting.
 - The switch is pushed again, irradiation of X-Ray is stopped.
- Indicator Lamp for Over Heart

- The Red Lamp will be lighting, if the X-Ray generator is over heated, and the generator of the X-Ray is stopped automatically.
 - In this case, the power supply will be maintains ON. Then, cooling to the generator will be started automatically.
 - The red lamp is light-out automatically when the system becomes normal. The system can be used again.
 - Irradiation of X-Ray can be used about continuously for 1 hour.
 - We recommend you it to turn off the switch of the X-Ray operation briskly when the irradiation is unnecessary.
- The Adjuster for X-Ray Current
 - It is fixed in contrast and the brightness of the image can be changed.
 - The image will become bright if current is increased.
 - The Adjuster of the X-Ray Voltage
 - Penetration power will become strongly if the voltage is made high. In this case, contrast of the image will become bad.
 - The Hours Counter
 - The counter will be counts the time of the power switch is ON.
 -

The skillful usage for the X-Ray System.

We recommend the power switch may be turned OFF when not irradiating X-Rays for a long time. Then the life of the X-Ray generator will become long.

4-2. Circuit Breaker

There is the circuit breaker in the left of the main body.

- If the breaker switch is OFF when the system is operation.
 - The power switch is OFF first.
 - Please reset of the breaker switch.

- * In the case of the breaker switch is OFF again, please pull out the power cable from the power supply socket. Then, please contact to the technical service.

4-3. X-Ray Interlock

- If the door of the system opened with carelessly when the X-Ray is irradiated. The X-Ray generator will be stopped automatically.
In this case, please shut the door first. Then, turn ON the switch of the X-Ray, The system will be re-operated.
- The sensor for the X-Ray interlock is setting upped on the upper of right hand side of the door.

<p>Caution : Please ON-OFF of X-Ray irradiation by the switch on the System. It does not ON-OFF with the switch for interlocks in the door.</p>
--

4-4. Indication Lamp for X-Ray Operation

- Indicator lamp for X-Ray is blinking in yellow when the irradiated of X-Ray.
- If the indicator lamp is blinking, please be careful not open the door of the system.

5. Principal Specifications


Model		MSX500	
X-Ray Tube	Tube Voltage	70KV maximum	
	Tube Current	3mA maximum	
	Focus Size	0.8mm	
	Cooling	Air cooling	
Detector	X-Ray CCD camera	2/3 inch (input size)	
Computer	CPU	1.2GHz	
	Memory	128MB	
	Storage	CD-R/W/FDD3.5/HDD20GB	
	OS	Windows2000	
	CRT	15inch	
	Image Controller	Improving image quality	
		Image enhancement processing	
Contrast adjustment			
Brightness adjustment			
Main Body	Dimensions	630W×745H×755Dmm (Body)	
	Weight	120K g approximately	
	Power Supply Capacity	100V AC (110,220,380,V AC) 500VA	
	Radiation (X-Ray)	Less than 1 μ Sv/h	
	X-Ray shield	X-Ray proofed special cabinet	
	X-Ray image magnification	30x	
	Table size	330×250mm	
	Table stroke.	X stroke	120mm
		Y stroke	160mm

Specification may be changed without a preliminary announcement for improvement.

6. Warranty

The system was shipped by strict quality control and inspection.

However, please inform the technical service with the serial number of the system, if there is should be fault.



In the event of a malfunction attributable to the manufacturer, the system will be repaired at no charge for one year from the date of the delivery of the system and or the hours worked of the system are till 3000 hours. It is till which or an early condition due date.

Any malfunction due to an act of God, a willful act, or an operator error will be repaired at a cost. This warranty will not cover any malfunction due to events beyond the control of the manufacturer. (e.g., acts of war)

7. Vision System

7-1. Abstract

The picture obtained with X ray system is possible into a clear and legible image with PC with the application software built in the system.

PC Conditions:

- IMB AT Compatible machine
- CPU : 1.2GHZ
- RAM : 128MB
- OS : Windows 2000
- CRT : Full colored 14 inch CRT
- Vision Board : FVX-CS-RICE/WIN

Operation Items:


- Brightness Control (at LIVE)
- Contrast Control (at LIVE)
- Image Enhancement (at Integration)
- Contrast Enhancement (at Integration)
- Data Saving
- Cross Cursor

Note: Please power switch ON in the Main Body first, and next, power switch of the PC must be ON. The software will not be start if the process is mistake.

7-2. Operation procedure

The application software is already installed on the PC, So, please start the system as the next process:

1. Power switch is ON of the Main body of the X Ray System.
2. Power switch is ON of the PC, You can see the below screen.




3. Icon of “Modulate” should be double crick,
4. Vision Screen is opened on the screen.
5. If an error message comes out in this process, please shut off all power supplies and perform the process of 1 to 4 again.
6. When you end operation, please click X at the upper right of the screen.

7-3. LIVE picture control

When IB- software was started, the picture from the X ray system is real-timely displayed on the screen.

The screen is in a LIVE




- ① : Operation is in LIVE
- ② : The mark is displayed by **GREEN** when operation is in LIVE
- ③ : Brightness control: The position 0 is center of the bright of the image.
- ④ : Contrast control: The position 0 is center of the contrast of the image.

Please on to the next step if the screen which you need can be displayed,

7-4. integrated picture control

The LIVE picture is contained an X ray noise. Then integration processing is in order to obtain a more cleared picture.



- ① : The number of times of integration is chosen from four stages. The picture will be cleared if chosen large number, but in the case, the time will be long.
- ② : The key which chooses LIVE or RESULT, when you chosen the RESULT, in the case, Wait... will be indicated in the window and ④ will be displayed "Yellow". And then "Red" if the integration was completed.
- ③ : LIVE---Wait....---RESULT, It shows the function that selected.
- ④ : **Green** at LIVE, **Yellow** at Wait..., **Red** at RESULT are lighting.
- ⑤ : REJ: Setting of contrast enhancement range in black level. (0-255)
- ⑥ : SAT: Setting of contrast enhancement range in white level. (0-255)

7-5. Data Save

Please loading and saving of the data on OS of WINDOWS.

The data can be saving as file mode of bmp or jpeg.

The data can do processing freely by the application software which can be operated with the same file mode. For example, they are the photo-shop, Microsoft Photo Draw etc.

7-6. Cross Cursor

If View (V) at the upper left of a screen is clicked, cross cursor will appears on the screen.

It is convenient to check of the center position of the screen, and the level of a picture.